— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250

— modifications are inspected and tested and operations and maintenance personnel receive appropriate training on the changes;

— modifications are promptly and completely documented; and

— a record of all MOC activities is kept.

PCSs have the characteristic that many values, some of which may be critical to process operation and safety, can be relatively easily changed. It is important that MOC procedures are also followed for these types of changes. Examples of PCS changes that should fall under MOC are listed below. This is not a complete list and the owner or operator needs to determine if other types of changes may need to be administered through MOC procedures:

— alarm setting, priority, enable/disable, etc. of all alarms that are identified as critical or protective;

— changes in control algorithms or control schemes, or operating graphics;

— changes in measurement device types, calibration, or measured ranges;

— addition or deletion of measurements, transmitters, switches, final control elements, etc.;

— PCS hardware or software updates;

— changes in power distribution to PCSs;

— changes in communications design, routing, or equipment.

8.3 Operations

8.3.1 General Responsibilities

The primary function of an operations group is to safely and economically operate the process equipment and the process to which they are assigned. This function requires a variety of skills, many of which are not within the scope of this document. However, in almost all cases, the primary method that the operators use to interface with the process is the PCS—which at its most basic function serves as the nervous system of a process—it provides the sensing of process variables, transmission of the sensing to a means of displaying the information to an operator and provides varying levels of process control, process alerts, and abnormal situation alarms and responses.

Therefore, one of the primary responsibilities of an operations group is to be able to properly interface with the PCS to run the process and understand and respond to abnormal situations involving both the process and the PCS. The fundamental responsibilities are as follows.

— Monitoring the process through the PCSs. This includes understanding the process, how to navigate among the various types of displays available, and understanding how the data are displayed.

— Executing a variety of commands to the process through the PCS such as commands to regulatory controls, manual operations such as startup and shutdown operations, and any other interactions required by the design of the controls specific to the process design.

— Accessing, interpreting, and responding to process alarms, alerts, and messages that are generated by the PCS.

— Operating any advanced control applications implemented in the PCS.

— Providing any routine inputs or reports required by process, safety, or environmental status and reporting systems implemented in or through the PCS.

Accessed by account: North Carolina A & T State | Date: Thu Feb 25 13:17:01 2021 | IP address: 152.8.254.250