



IEC 62428

Edition 1.0 2008-07

INTERNATIONAL STANDARD

NORME INTERNATIONALE

**Electric power engineering – Modal components in three-phase a.c. systems –
Quantities and transformations**

**Energie électrique – Composantes modales dans les systèmes a.c. triphasés –
Grandeurs et transformations**

LICENSED TO MECON Limited. - RANCHI/BANGALORE
FOR INTERNAL USE AT THIS LOCATION ONLY, SUPPLIED BY BOOK SUPPLY BUREAU.



THIS PUBLICATION IS COPYRIGHT PROTECTED

Copyright © 2008 IEC, Geneva, Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either IEC or IEC's member National Committee in the country of the requester.

If you have any questions about IEC copyright or have an enquiry about obtaining additional rights to this publication, please contact the address below or your local IEC member National Committee for further information.

Droits de reproduction réservés. Sauf indication contraire, aucune partie de cette publication ne peut être reproduite ni utilisée sous quelque forme que ce soit et par aucun procédé, électronique ou mécanique, y compris la photocopie et les microfilms, sans l'accord écrit de la CEI ou du Comité national de la CEI du pays du demandeur.

Si vous avez des questions sur le copyright de la CEI ou si vous désirez obtenir des droits supplémentaires sur cette publication, utilisez les coordonnées ci-après ou contactez le Comité national de la CEI de votre pays de résidence.

IEC Central Office
3, rue de Varembé
CH-1211 Geneva 20
Switzerland
Email: inmail@iec.ch
Web: www.iec.ch

About the IEC

The International Electrotechnical Commission (IEC) is the leading global organization that prepares and publishes International Standards for all electrical, electronic and related technologies.

About IEC publications

The technical content of IEC publications is kept under constant review by the IEC. Please make sure that you have the latest edition, a corrigenda or an amendment might have been published.

- Catalogue of IEC publications: www.iec.ch/searchpub

The IEC on-line Catalogue enables you to search by a variety of criteria (reference number, text, technical committee,...). It also gives information on projects, withdrawn and replaced publications.

- IEC Just Published: www.iec.ch/online_news/justpub

Stay up to date on all new IEC publications. Just Published details twice a month all new publications released. Available on-line and also by email.

- Electropedia: www.electropedia.org

The world's leading online dictionary of electronic and electrical terms containing more than 20 000 terms and definitions in English and French, with equivalent terms in additional languages. Also known as the International Electrotechnical Vocabulary online.

- Customer Service Centre: www.iec.ch/webstore/custserv

If you wish to give us your feedback on this publication or need further assistance, please visit the Customer Service Centre FAQ or contact us:

Email: csc@iec.ch

Tel.: +41 22 919 02 11

Fax: +41 22 919 03 00

A propos de la CEI

La Commission Electrotechnique Internationale (CEI) est la première organisation mondiale qui élabore et publie des normes internationales pour tout ce qui a trait à l'électricité, à l'électronique et aux technologies apparentées.

A propos des publications CEI

Le contenu technique des publications de la CEI est constamment revu. Veuillez vous assurer que vous possédez l'édition la plus récente, un corrigendum ou amendement peut avoir été publié.

- Catalogue des publications de la CEI: www.iec.ch/searchpub/cur_fut-f.htm

Le Catalogue en-ligne de la CEI vous permet d'effectuer des recherches en utilisant différents critères (numéro de référence, texte, comité d'études,...). Il donne aussi des informations sur les projets et les publications retirées ou remplacées.

- Just Published CEI: www.iec.ch/online_news/justpub

Restez informé sur les nouvelles publications de la CEI. Just Published détaille deux fois par mois les nouvelles publications parues. Disponible en-ligne et aussi par email.

- Electropedia: www.electropedia.org

Le premier dictionnaire en ligne au monde de termes électroniques et électriques. Il contient plus de 20 000 termes et définitions en anglais et en français, ainsi que les termes équivalents dans les langues additionnelles. Egalement appelé Vocabulaire Electrotechnique International en ligne.

- Service Clients: www.iec.ch/webstore/custserv/custserv_entry-f.htm

Si vous désirez nous donner des commentaires sur cette publication ou si vous avez des questions, visitez le FAQ du Service clients ou contactez-nous:

Email: csc@iec.ch

Tél.: +41 22 919 02 11

Fax: +41 22 919 03 00



IEC 62428

Edition 1.0 2008-07

INTERNATIONAL STANDARD

NORME INTERNATIONALE

**Electric power engineering – Modal components in three-phase a.c. systems –
Quantities and transformations**

**Energie électrique – Composantes modales dans les systèmes a.c. triphasés –
Grandeur et transformations**

INTERNATIONAL
ELECTROTECHNICAL
COMMISSION

COMMISSION
ELECTROTECHNIQUE
INTERNATIONALE

PRICE CODE
CODE PRIX

S

ICS 01.060; 29.020

ISBN 2-8318-9921-4

CONTENTS

FOREWORD.....	3
1 Scope.....	5
2 Normative references	5
3 Terms, definitions, quantities and concepts	5
3.1 General	5
3.2 Terms and definitions	5
4 Modal transformation.....	7
4.1 General	7
4.2 Power in modal components.....	8
4.3 Established transformations	10
5 Decoupling in three-phase a.c. systems	16
5.1 Decoupling in case of steady-state operation with sinusoidal quantities.....	16
5.2 Decoupling under transient conditions	19
Bibliography.....	23

Figure 1 – Circuit, fed by a three-phase voltage source with U_{L1Q} , U_{L2Q} , U_{L3Q} at the connection point Q and earthed at the neutral point N via the impedance $Z_N = R_N + jX_N$	16
--	----

Figure 2 – Three decoupled systems which replace the coupled three-phase a.c. system of Figure 1 under the described conditions (see text)	19
--	----

Table 1 – Power-variant form of modal components and transformation matrices.....	11
Table 2 – Power-invariant form of modal components and transformation matrices	12
Table 3 – Clark, Park and space phasor components – modal transformations in the power-variant form	13
Table 4 – Clark, Park and space phasor components – Modal transformations in the power-invariant form	14
Table 5 – Transformation matrices in the power-variant form for phasor quantities	15
Table 6 – Transformation matrices in the power-invariant form for phasor quantities.....	15
Table 7 – Modal voltages and impedances in case of phasor quantities	18
Table 8 – Modal voltages and inductances under transient conditions.....	22

INTERNATIONAL ELECTROTECHNICAL COMMISSION

**ELECTRIC POWER ENGINEERING –
MODAL COMPONENTS IN THREE-PHASE AC SYSTEMS –
QUANTITIES AND TRANSFORMATIONS**

FOREWORD

- 1) The International Electrotechnical Commission (IEC) is a worldwide organization for standardization comprising all national electrotechnical committees (IEC National Committees). The object of IEC is to promote international co-operation on all questions concerning standardization in the electrical and electronic fields. To this end and in addition to other activities, IEC publishes International Standards, Technical Specifications, Technical Reports, Publicly Available Specifications (PAS) and Guides (hereafter referred to as "IEC Publication(s)"). Their preparation is entrusted to technical committees; any IEC National Committee interested in the subject dealt with may participate in this preparatory work. International, governmental and non-governmental organizations liaising with the IEC also participate in this preparation. IEC collaborates closely with the International Organization for Standardization (ISO) in accordance with conditions determined by agreement between the two organizations.
- 2) The formal decisions or agreements of IEC on technical matters express, as nearly as possible, an international consensus of opinion on the relevant subjects since each technical committee has representation from all interested IEC National Committees.
- 3) IEC Publications have the form of recommendations for international use and are accepted by IEC National Committees in that sense. While all reasonable efforts are made to ensure that the technical content of IEC Publications is accurate, IEC cannot be held responsible for the way in which they are used or for any misinterpretation by any end user.
- 4) In order to promote international uniformity, IEC National Committees undertake to apply IEC Publications transparently to the maximum extent possible in their national and regional publications. Any divergence between any IEC Publication and the corresponding national or regional publication shall be clearly indicated in the latter.
- 5) IEC provides no marking procedure to indicate its approval and cannot be rendered responsible for any equipment declared to be in conformity with an IEC Publication.
- 6) All users should ensure that they have the latest edition of this publication.
- 7) No liability shall attach to IEC or its directors, employees, servants or agents including individual experts and members of its technical committees and IEC National Committees for any personal injury, property damage or other damage of any nature whatsoever, whether direct or indirect, or for costs (including legal fees) and expenses arising out of the publication, use of, or reliance upon, this IEC Publication or any other IEC Publications.
- 8) Attention is drawn to the Normative references cited in this publication. Use of the referenced publications is indispensable for the correct application of this publication.
- 9) Attention is drawn to the possibility that some of the elements of this IEC Publication may be the subject of patent rights. IEC shall not be held responsible for identifying any or all such patent rights.

International Standard IEC 62428 has been prepared by IEC technical committee 25: Quantities and units.

The text of this standard is based on the following documents:

FDIS	Report on voting
25/382/FDIS	25/390/RVD

Full information on the voting for the approval of this standard can be found in the report on voting indicated in the above table.

This publication has been drafted in accordance with the ISO/IEC Directives, Part 2.

The committee has decided that the contents of this publication will remain unchanged until the maintenance result date indicated on the IEC web site under "http://webstore.iec.ch" in the data related to the specific publication. At this date, the publication will be

- reconfirmed;
- withdrawn;
- replaced by a revised edition; or
- amended.

ELECTRIC POWER ENGINEERING – MODAL COMPONENTS IN THREE-PHASE AC SYSTEMS – QUANTITIES AND TRANSFORMATIONS

1 Scope

This International Standard deals with transformations from original quantities into modal quantities for the widely used three-phase a.c. systems in the field of electric power engineering.

The examination of operating conditions and transient phenomena in three-phase a.c. systems becomes more difficult by the resistive, inductive or capacitive coupling between the phase elements and line conductors. Calculation and description of these phenomena in three-phase a.c. systems are easier if the quantities of the coupled phase elements and line conductors are transformed into modal quantities. The calculation becomes very easy if the transformation leads to decoupled modal systems. The original impedance and admittance matrices are transformed to modal impedance and admittance matrices. In the case of decoupling of the modal quantities, the modal impedance and admittance matrices become diagonal matrices.

2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

IEC 60050-141, *International Electrotechnical Vocabulary (IEV) – Part 141: Polyphase systems and circuits*

3 Terms, definitions, quantities and concepts

3.1 General

Quantities in this standard are usually time-dependent. These quantities are for instance electric currents, voltages, linked fluxes, current linkages, electric and magnetic fluxes.

For quantities the general letter symbol g in case of real instantaneous values, \underline{g} in case of complex instantaneous values and $\underline{\underline{G}}$ in case of phasors (complex r.m.s. values) are used.

NOTE Complex quantities in this standard are underlined. Conjugated complex quantities are indicated by an additional asterisk (*). Matrices and column vectors are printed in bold face type, italic.

3.2 Terms and definitions

For the purposes of this document, the terms and definitions given in IEC 60050-141 and the following apply.

3.2.1

original quantities

quantities g or \underline{G} of a three-phase a.c. system

NOTE Subscripts 1, 2, 3 are generally used in this standard; additional letters may be put, for instance L1, L2, L3 as established in IEC 60909, IEC 60865 and IEC 61660.

3.2.2

modal components

quantities g_M , \underline{g}_M or $\underline{\underline{G}}_M$ found by a transformation from the original quantities according to Clause 3

NOTE Additional subscripts 1, 2, 3 are used.

3.2.3

column vector of quantities

column matrix containing the three original quantities or modal components of a three-phase a.c. system

NOTE Column vectors are described by \mathbf{g} or $\underline{\mathbf{g}}_M$ and \mathbf{G} or $\underline{\underline{\mathbf{G}}}_M$, respectively.

3.2.4

modal transformation

matrix equation $\underline{\mathbf{T}} \mathbf{g}_M = \mathbf{g}$ for a column vector \mathbf{g}_M containing the three unknown modal quantities, where \mathbf{g} is a column vector containing the three given original quantities and $\underline{\mathbf{T}}$ is a 3×3 transformation matrix

NOTE The transformation can be power-variant or power-invariant, see Tables 1 and 2.

3.2.5

inverse modal transformation

solution $\mathbf{g}_M = \underline{\mathbf{T}}^{-1} \mathbf{g}$ of the modal transformation that expresses a column vector \mathbf{g}_M containing the three modal quantities as a matrix product of the inverse transformation matrix $\underline{\mathbf{T}}^{-1}$ by a column vector \mathbf{g} containing the three original quantities

3.2.6

transformation into symmetrical components

Fortescue transformation

linear modal transformation with constant complex coefficients, the solution of which converts the three original phasors of a three-phase a.c. system into the reference phasors of three symmetric three-phase a.c. systems — the so-called symmetrical components — , the first system being a positive-sequence system, the second system being a negative-sequence system and the third system being a zero-sequence system

NOTE 1 The transformation into symmetrical components is used for example for the description of asymmetric steady-state conditions in three-phase a.c. systems.

NOTE 2 See Tables 1 and 2.

3.2.7

transformation into space phasor components

linear modal transformation with constant or angle-dependent coefficients, the solution of which replaces the instantaneous original quantities of a three-phase a.c. system by the complex space phasor in a rotating or a non-rotating frame of reference, its conjugate complex value and the real zero-sequence component

NOTE 1 The term "space vector" is also used for "space phasor".

NOTE 2 The space phasor transformation is used for example for the description of transients in three-phase a.c. systems and machines.

NOTE 3 See Tables 1 and 2.

3.2.8

transformation into $\alpha\beta 0$ components

Clarke transformation

linear modal transformation with constant real coefficients, the solution of which replaces the instantaneous original quantities of a three-phase a.c. system by the real part and the

imaginary part of a complex space phasor in a non-rotating frame of reference and a real zero-sequence component or replaces the three original phasors of the three-phase a.c. system by two phasors (α and β phasor) and a zero-sequence phasor

NOTE 1 The power-variant form of the space phasor is given by $\underline{g}_s = g_\alpha + j g_\beta$ and the power-invariant form is given by $\underline{g}_s = \frac{1}{\sqrt{2}}(g_\alpha + j g_\beta)$.

NOTE 2 The $\alpha\beta0$ transformation is used for example for the description of asymmetric transients in three-phase a.c. systems.

NOTE 3 See tables 1 and 2.

3.2.9

transformation into dq0 components

Park transformation

linear modal transformation with coefficients sinusoidally depending on the angle of rotation, the solution of which replaces the instantaneous original quantities of a three-phase a.c. system by the real part and the imaginary part of a complex space phasor in a rotating frame of reference and a real zero-sequence component

NOTE 1 The power-variant form of the space phasor is given by $\underline{g}_r = g_d + j g_q$ and the power-invariant form is given by $\underline{g}_r = \frac{1}{\sqrt{2}}(g_d + j g_q)$.

NOTE 2 The dq0 transformation is normally used for the description of transients in synchronous machines.

NOTE 3 See Tables 1 and 2.

4 Modal transformation

4.1 General

The original quantities g_1, g_2, g_3 and the modal components $\underline{g}_{M1}, \underline{g}_{M2}, \underline{g}_{M3}$ are related to each other by the following transformation equations:

$$\begin{pmatrix} g_1 \\ g_2 \\ g_3 \end{pmatrix} = \begin{pmatrix} t_{11} & t_{12} & t_{13} \\ t_{21} & t_{22} & t_{23} \\ t_{31} & t_{32} & t_{33} \end{pmatrix} \begin{pmatrix} \underline{g}_{M1} \\ \underline{g}_{M2} \\ \underline{g}_{M3} \end{pmatrix} \quad (1)$$

or in a shortened form:

$$\underline{g} = \underline{T} \underline{g}_M \quad (2)$$

The coefficients t_{ik} of the transformation matrix \underline{T} can all be real or some of them can be complex. It is necessary that the transformation matrix \underline{T} is non-singular, so that the inverse relationship of Equation (2) is valid.

$$\underline{g}_M = \underline{T}^{-1} \underline{g} \quad (3)$$

If the original quantities are sinusoidal quantities of the same frequency, it is possible to express them as phasors and to write the transformation Equations (2) and (3) in an analogue form with constant coefficients:

$$\begin{pmatrix} \underline{G}_1 \\ \underline{G}_2 \\ \underline{G}_3 \end{pmatrix} = \begin{pmatrix} t_{11} & t_{12} & t_{13} \\ t_{21} & t_{22} & t_{23} \\ t_{31} & t_{32} & t_{33} \end{pmatrix} \begin{pmatrix} \underline{G}_{M1} \\ \underline{G}_{M2} \\ \underline{G}_{M3} \end{pmatrix} \quad (4)$$

$$\underline{G} = \underline{T} \underline{G}_M \quad (5)$$

$$\underline{G}_M = \underline{T}^{-1} \underline{G} \quad (6)$$

4.2 Power in modal components

Transformation relations are used either in the power-variant form as given in Table 1 or in the power-invariant form as given in Table 2.

For the power-invariant form of transformation, the power calculated with the three modal components is equal to the power calculated from the original quantities of a three-phase a.c. system with three line conductors and a neutral conductor, where u_1 , u_2 and u_3 are the line-to-neutral voltages and i_1 , i_2 and i_3 are the currents of the line conductors at a given location of the network. In a three-phase a.c. system with only three line conductors, u_1 , u_2 and u_3 are the voltages between the line conductors and a virtual star point at a given location of the network.

The instantaneous power p expressed in terms of the original quantities is defined by:

$$p = u_1 i_1^* + u_2 i_2^* + u_3 i_3^* = (u_1 \ u_2 \ u_3) \begin{pmatrix} i_1^* \\ i_2^* \\ i_3^* \end{pmatrix} = \underline{u}^T \underline{i}^* \quad (7)$$

NOTE The asterisks denote formally the complex conjugate of the currents i_1 , i_2 , i_3 . If these are real, i_1^* , i_2^* , i_3^* are identical to i_1 , i_2 , i_3 .

If the relationship between the original quantities and the modal components given in Equation (2) is introduced for the voltages as well as for the currents:

$$\underline{u} = \underline{T} \underline{u}_M \text{ and } \underline{i} = \underline{T} \underline{i}_M \quad (8)$$

taking into account

$$\underline{u}^T = (\underline{T} \underline{u}_M)^T = \underline{u}_M^T \underline{T}^T, \quad (9)$$

the power p expressed in terms of modal components is found as:

$$p = \underline{u}_M^T \underline{T}^T \underline{T}^* \underline{i}_M^*. \quad (10)$$

For the power-variant case where $\underline{T}^T \underline{T}^*$ is not equal to the unity matrix an example is given at the end of this section. In case of

$$\underline{T}^T \underline{T}^* = \underline{E} \quad (11)$$

with the matrix E being the unity matrix of third order, Equation (10) changes to

$$p = \underline{U}_M^T \underline{I}_M^* = (\underline{u}_{M1} \quad \underline{u}_{M2} \quad \underline{u}_{M3}) \begin{pmatrix} i_{M1}^* \\ i_{M2}^* \\ i_{M3}^* \end{pmatrix} = \underline{u}_{M1} i_{M1}^* + \underline{u}_{M2} i_{M2}^* + \underline{u}_{M3} i_{M3}^*. \quad (12)$$

The condition $\underline{T}^T \underline{T}^* = E$ or $\underline{T}^{-1} = \underline{T}^{T*}$ means that the transformation matrix \underline{T} is a unitary matrix.

Because the Equations (7) and (12) have identical structure, the transformation relationship with a unitary matrix is called the power invariant form of transformation.

In connection with Table 2, the following examples can be given:

$$p_{\alpha\beta 0} = u_\alpha i_\alpha + u_\beta i_\beta + u_0 i_0$$

$$p_{dq0} = u_d i_d + u_q i_q + u_0 i_0$$

$$p_{ss^*0} = \underline{u}_s i_s^* + \underline{u}_s^* i_s + u_0 i_0 = 2\text{Re}\{\underline{u}_s i_s^*\} + u_0 i_0$$

$$p_{rr^*0} = \underline{u}_r i_r^* + \underline{u}_r^* i_r + u_0 i_0 = 2\text{Re}\{\underline{u}_r i_r^*\} + u_0 i_0$$

In case of three-phase systems of voltages and currents the complex power is given in original phasor quantities as follows:

$$\underline{S} = \underline{U}_1 \underline{I}_1^* + \underline{U}_2 \underline{I}_2^* + \underline{U}_3 \underline{I}_3^* = (\underline{U}_1 \quad \underline{U}_2 \quad \underline{U}_3) \begin{pmatrix} I_1^* \\ I_2^* \\ I_3^* \end{pmatrix} = \underline{U}^T \underline{I}^* \quad (13)$$

Substituting the modal components by

$$\underline{U}^T = (\underline{T} \underline{U}_M)^T = \underline{U}_M^T \underline{T}^T \text{ and } \underline{I}^* = \underline{T}^* \underline{I}_M^*$$

the complex apparent power is found as:

$$\underline{S} = \underline{U}_M^T \underline{T}^T \underline{T}^* \underline{I}_M^* \quad (14)$$

In case of power invariance, the condition $\underline{T}^T \underline{T}^* = E$ must also be valid. Then Equation (14) leads to the following power invariant expression:

$$\underline{S} = \underline{U}_M^T \underline{I}_M^* = \underline{U}_{M1} I_{M1}^* + \underline{U}_{M2} I_{M2}^* + \underline{U}_{M3} I_{M3}^* = (\underline{U}_{M1} \quad \underline{U}_{M2} \quad \underline{U}_{M3}) \begin{pmatrix} I_{M1}^* \\ I_{M2}^* \\ I_{M3}^* \end{pmatrix} \quad (15)$$

The power-variant forms of transformation matrices are given in the Tables 3 and 5. They are also known as reference-component-invariant transformations, because, under balanced

symmetrical conditions, the reference component (the first component) of the modal components is equal to the reference component of the original quantities or its complex phasors, respectively. This is not the case for transformations in a rotating frame.

EXAMPLE According to Table 2 for the power-invariant form of the transformation matrix \underline{T} it follows:

$$\underline{T} = \frac{1}{\sqrt{3}} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}, \quad \underline{T}^T = \frac{1}{\sqrt{3}} \begin{pmatrix} 1 & \underline{a}^2 & \underline{a} \\ 1 & \underline{a} & \underline{a}^2 \\ 1 & 1 & 1 \end{pmatrix}, \quad \underline{T}^{T*} = \frac{1}{\sqrt{3}} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix},$$

showing that $\underline{T}^{-1} = \underline{T}^{T*}$ or $\underline{T}^T \underline{T}^* = E$, fulfilling the condition for power invariance.

If the transformation matrix \underline{T} from Table 1 for the power-variant transformation is used, then the following results are found:

$$\underline{T} = \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}, \quad \underline{T}^T = \begin{pmatrix} 1 & \underline{a}^2 & \underline{a} \\ 1 & \underline{a} & \underline{a}^2 \\ 1 & 1 & 1 \end{pmatrix}, \quad \underline{T}^{T*} = \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}.$$

\underline{T}^{-1} from Table 1 is equal to $\frac{1}{3}\underline{T}^{T*}$, so that $\underline{T}^T \underline{T}^* = 3 \cdot E$.

4.3 Established transformations

The most widely used transformation matrices \underline{T} and their inverse matrices \underline{T}^{-1} are given in the Tables 1 and 2, whereby Table 1 contains the power-variant (reference-component-invariant) form and Table 2 the power-invariant form of transformation matrices. The subscripts for the components are chosen to be equal in both cases of Tables 1 and 2, 3 and 4, 5 and 6.

The Tables 3 to 6 give the relations between the different types of modal components.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned}
 c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\
 s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0.
 \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.

Table 1 – Power-variant form of modal components and transformation matrices

Modal components	Component:	Subscript:	\underline{T}_a	\underline{T}^{-1}
	First	M1		
	Second	M2		
(Fortescue components)	Third	M3		
	positive-sequence	(1)	$\begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{1}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ 1 & 1 & 1 \end{pmatrix}$
	negative-sequence	(2)		
	zero-sequence	(0) b		
(Clarke components)	α	α	$\begin{pmatrix} 1 & 0 & 1 \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} & 1 \\ -\frac{1}{2} & -\frac{\sqrt{3}}{2} & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & -\frac{1}{2} & -\frac{1}{2} \\ 0 & \frac{\sqrt{3}}{2} & -\frac{\sqrt{3}}{2} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	β	β		
	zero-sequence	0		
(Park components)	direct-axis	d	$\begin{pmatrix} c_1 & -s_1 & 1 \\ c_2 & -s_2 & 1 \\ c_3 & -s_3 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} c_1 & c_2 & c_3 \\ -s_1 & -s_2 & -s_3 \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	quadrature-axis	q		
	zero-sequence	0		
space phasor components, non-rotating frame	space phasor	s	$\frac{1}{2} \begin{pmatrix} 1 & 1 & 1 \\ \underline{a}^2 & \underline{a} & 1 \\ \underline{a} & \underline{a}^2 & 1 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} 1 & \underline{a} & \underline{a}^2 \\ 1 & \underline{a}^2 & \underline{a} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	s^*		
	zero-sequence	0		
space phasor components, rotating frame	space phasor	r	$\frac{1}{2} \begin{pmatrix} e^{j\vartheta} & e^{-j\vartheta} & 2 \\ \underline{a}^2 e^{j\vartheta} & \underline{a} e^{-j\vartheta} & 2 \\ \underline{a} e^{j\vartheta} & \underline{a}^2 e^{-j\vartheta} & 2 \end{pmatrix}$	$\frac{2}{3} \begin{pmatrix} e^{-j\vartheta} & \underline{a} & e^{-j\vartheta} & \underline{a}^2 e^{-j\vartheta} \\ e^{j\vartheta} & \underline{a}^2 e^{j\vartheta} & \underline{a} & e^{j\vartheta} \\ \frac{1}{2} & \frac{1}{2} & \frac{1}{2} \end{pmatrix}$
	conjugated complex space phasor	r^*		
	zero-sequence	0		

^a All the transformation matrices \underline{T} given here fulfil the following conditions:

$$t_{11} + t_{21} + t_{31} = 0, \quad t_{12} + t_{22} + t_{32} = 0, \quad t_{13} = t_{23} = t_{33}.$$

^b The IEC Standards 60909, 60865 and 61660 have introduced the subscripts (1), (2), (0) for the power-variant form of the symmetrical components, to avoid confusion, if the subscripts 1, 2, 3 instead of L1, L2, L3 are used.

$$\begin{aligned} c_1 &= \cos \vartheta, & c_2 &= \cos(\vartheta - \frac{2\pi}{3}), & c_3 &= \cos(\vartheta + \frac{2\pi}{3}), & s_1 &= \sin \vartheta, & s_2 &= \sin(\vartheta - \frac{2\pi}{3}), \\ s_3 &= \sin(\vartheta + \frac{2\pi}{3}), & \underline{a} &= e^{j2\pi/3}, & \underline{a}^2 &= \underline{a}^*, & 1 + \underline{a} + \underline{a}^2 &= 0. \end{aligned}$$

In case of synchronous machines ϑ is given by $\vartheta = \int \Omega(t) dt$, where Ω is the instantaneous angle velocity of the rotor.